

INSTALLATION INSTRUCTIONS FOR NP-TOPP ON TOP PHONE CHARGER:

Kit includes:

On-top coil(antenna)

Table Dock (mounted on underside of table)

Battery

4 screws

TOOLS REQUIRED-

Measuring tape

Phillips head screwdriver

Drill with 5/8" bit

Mounting instructions:

1. Confirm clearance for table dock on the underside of the table where you wish to install the charger. Make sure table base will not obstruct table dock placement.
2. Mark a spot on the table top to make a hole using the drill and 5/8" bit. A distance of 3 ¼" from the table edge is suggested
3. Remove the adhesive from the back of the On-top coil and feed the wires of the coil into the hole to the underside of the table.
4. Firmly press the coil in place.
5. Position the table dock base on the underside of the table over the hole with the red coil connectors towards the table edge and the wires fed through the opening in front of the connectors.
6. Secure the dock to the table by screwing it in place with the 4 screws.
7. Compress each of the red buttons and insert a white wire into each of the holes below the button.
8. Plug the white connector of the dock hood into the dock base and close the hood.
9. Slide the charged battery into the dock.

BATTERY CHARGING:

Insert the battery into the charging station, (sold separately) that is plugged into a power source. Light will flash red while charging and will turn green when fully charged.

Use the Magnetic Key, (also sold separately) to remove the battery from the table docking station by inserting it into the opening between the USB ports and pulling trigger.