



TRIBECA TABLETOP INSTALLATION INSTRUCTIONS:

BFM Seating's Tribeca tabletops are made of an extremely dense, hard, compact laminate material that is UV and weather resistant, as well as extremely resistant to abrasion and scratching. The unique qualities of the material require that special care be taken in installation to avoid damaging the top.

Tribeca tops have been predrilled to be attached to specific BFM Seating table bases and should only be used with these. Use with other bases can void the warranty. The appropriate screws needed for attaching the bases are supplied and can be found in a small bright green cardboard box. If you cannot find these screws, contact the factory. Do not use other screws without contacting BFM first.

- To install the top to a base, place the top on clean, smooth, hard surface, top down with the predrilled holes facing up.
- Align the top plate of the fully assembled table base with the predrilled holes on the underside of the tabletop.
- Insert two of the screws into holes diagonal from each other. PLEASE NOTE: If washers are provided, they must be used for every screw. Using a Phillips head screwdriver or cordless drill with Phillips Head P3 bit.
- SLOWLY tighten a screw into your first hole to the point of being snug, without applying excessive pressure. It is recommended that if using a cordless drill, that it have a torque setting. DO NOT overtighten as this may cause the screw to strip out the hole or cause the top surface to chip. (turn the table over after inserting the first screw to insure the top surface was not penetrated.)
- Insert and tighten the remaining screws

Once you have inserted a screw in every available hole, carefully turn the table upright to be placed into service. When the top and base have been put together it is NOT RECOMMENDED that they be disassembled again.

For any questions on assembling please contact BFM Seating.

WWW.BFMSEATING.COM