

# Trash Receptacle





215-289-5411


## Assembly Instructions

Contents					
Ref.	Qty.	Description	Ref.	Qty.	Description
A	1	Top Panel	H1	28	Cam Lock
D	1	Back Panel	H2	28	Cam Post
C	1	Bottom Panel	H3	4	Dowel Pin
F	1	Toe Kick Panel	H4	12	Hinge Screw
B1	1	Left Side Panel	H5	2	Concealed Hinge
B2	1	Right Side Panel			
g	1	Top Swing Door			
H	1	Horizontal Tablet			
G	1	Door			


### CAM LOCKING DETAIL & SEQUENCE




4




5




6



7



8




SEE DETAIL A

TO ADJUST DOOR

loosen screws and adjust door and re-tighten

DETAIL A



H4